

Infrared Heater Panels

IHP Model Fitting Instructions

(Angled Mounting for Corners, Cornices and Underdesk)

Please read carefully before installing



In order to mount in a corner, IHP320a and IHP160a panels have C brackets attached to the 2 long sides of the panel. To install the panel, four mounting screws must be screwed into the wall or desk. The panel is then slides over these screws.

Four mounting screws and four screw plugs, together with a L shaped fitting template come with each panel. See picture. Detailed instructions are as follows.



Position the heater at 45 degree angle in the corner of wall, the cornice or the desk and modesty board for the underdesk heater. Mark the centre point of the brackets at the top of the panel.




Align the supplied template with one of the centre points. Using the holes in the template, mark the drill holes for 2 of the mounting screws. Repeat at the other centre.



Drill the 4 holes and insert the mounting screws. The screws should protrude some 6 mm so that the head of the screw can slide into the rail.



Slide the brackets over the mounting screws. Screw in one of the locks screws to lock the heater in place.



Plug the heater in and run till slightly warm. Remove the protective plastic coating.